



Owner's manual 2020

ENDURO SERIES

EC-RANGER 2T - 200 - 300CC

2019 GAS GAS

All rights reserved

Reprinting and reproduction of any kind, either in whole or in part, is prohibited without the written permission of the copyright holder.

The company has the right, without prior notice, to change the technical content of the products.

The models in the images may appear with special equipment that does not come with the standard model.

Edition 01/05/2019

Contents


GENERAL INFORMATION	7
INTRODUCTION	8
LEGAL NOTICES	8
NOTICES AND WARNINGS	8
PRELIMINARY WARNINGS	9
LOCATION OF COMPONENTS ECRANGER 200 / 300 CC	10
IDENTIFICATION	13
STEERING LOCK	13
SPECIFICATIONS	14
ELECTRIC DIAGRAM FOR ECRANGER 200 / 300 CC MODELS	17
Engine	20
MULTIFUNCTION GAUGE (EC MODELS ONLY)	23
Mode push-button	23
Adjustment push-button	23
HOMOLOGATION	24
OPERATING INSTRUCTIONS	26
STARTING PROCEDURE	27
BREAKING-IN	27
DAILY INSPECTION BEFORE RIDING	28
CLEANING	32
STORAGE	33
OBD OPERATION	33
MAINTENANCE	35
MAINTENANCE TABLE	36
MAINTENANCE	37
1.-Clutch	37
2.-Clutch discs	37
3.-Throttle cable	37
4.-Spark plug	37
5.-Air filter	38
6.-Carburettor	40
7.-Transmission oil	40
8.-Piston and ring	41
9. Cylinder head, cylinder and exhaust valve	41
10.-Exhaust system	41
11.-Muffler fibre	42
12.-Connecting rod and bearings	43
13.-Kick-starter and gear shift pedal	43
14.-Rubber gasket exhaust/silencer	43
15.-Motor bearings	43
16.-Coolant	43
17.-Radiator tube and connections	45
18.-Brakes adjustment	45
19.-Brakes wear	46
20.-Brake fluid	48
21.-Brake fluid level	48
22.-Brake pump piston and dust cover (front and rear)	48
23.-Calliper piston and dust cover (all callipers)	49

Contents

24.-Brake hoses	49
25 and 26.-Spokes and wheels	49
27.-Chain guide	49
28.-Chain guide wear	49
29.- Chain guide shoe	49
30.-Front Suspension	50
31.-Front suspension oil	51
32.-Bolts, nuts and fasteners	51
33.-Petrol tube	51
34.-Fuel system	52
35.-Steering head adjustment	52
36.-General lubrication	53
37.-Steering bearing	53
38.-Wheel bearing	53
39.-Swingarm and linkage	53
40.-Rear suspension	53
41.-Chain	56
42.-Tires	56
43.-Battery charge	57
SETTINGS	58
INTRODUCTION	59
CARBURATOR SETTING * FOR XC MODEL	59
Opening of the throttle valve and influences	59
Idle jet and mixing screw	59
Reference carburetion (competition only)	60
Carburettor needle	60
Main jet	60
Correction factors 200 / 300 cc.	61
SECONDARY TRANSMISSION RATIO	62
SUSPENSION SETTING	62
Available settings	62
SUSPENSION settings	63
Static sag	65
Correction according to type of terrain	65
Adjusting your motorcycle	65
SUSPENSION SETTING	66
CENTRIFUGAL EXTERNAL ADJUSTMENT SYSTEM	67
TROUBLESHOOTING	68
WARRANTY MANUAL	74



This page has been left blank intentionally.



A grayscale photograph of the front of a GasGas motorcycle. The image shows the handlebars with grips and controls, the front fork, a round headlight, and a smaller auxiliary light mounted on the front fender. The GasGas logo is visible on the upper part of the front fairing and on the fender.

GENERAL INFORMATION

Introduction

GAS GAS thanks you for your trust.

By choosing the new **GAS GAS ECRANGER 2020 or XC 2020** you have just joined the great **GAS GAS** team, and as a user of the number one brand of off-road bikes, you deserve the distinguished care that we would like to offer you, both after purchasing your **GAS GAS** and in the explanations that we set out in this manual.

Your **GAS GAS ECRANGER 2020** is a bike designed for high-level competition, it is the fruit of many years of competition and experience in demanding disciplines. The many successes achieved by the great riders of our **GAS GAS** bikes has provided the basic data to be able to create these high-end motorcycles. Exclusive **GAS GAS** motorcycles that have three key factors: **Reliability, high performance and good stability.**

Congratulations because your choice has undoubtedly been the right one. With your skills in handling your **GAS GAS** and with the proper preparation and the corresponding reviews, vital for your **GAS GAS** to be highly reliable, you can enjoy the most comfortable and fulfilling motorcycling.

Thank you for your trust and welcome to **GAS GAS**.

Legal notices

In the interest of technical development **GAS GAS** reserves the right to modify the construction, equipment and accessories of the motorcycle without prior notice. Measurements, weight and power data are understood to include the respective tolerances. Depending on the volume of equipment and accessories of your **GAS GAS**, as well as in the approved versions in accordance with the different laws of each State, there may be variations with respect to the descriptions and illustrations. Therefore, the photographs contained in this manual may not correspond to the model purchased. For this reason no liability shall be derived for error, printing error or omission.

Notices and warnings

Please read this manual thoroughly, paying particular attention to the following warnings:



DANGER

Notices about a danger that leads to serious injury or even death.



WARNING

Notices regarding danger that could result in personal injury and/or damage to the vehicle.

Preliminary warnings



DANGER

Three out of four fatal accidents are due to head injuries. The risk of brain injury is three times greater if no helmet is used. Always wear an approved helmet, the probability of remaining unscathed in the event of an accident is increased by 20%. It is also recommended to use eye protection as well as gloves, boots and other protective items that should be in perfect condition.

Never carry a passenger. Your **GAS GAS** is not approved for this purpose, nor does it have space on the seat, handlebars or footrests for the passenger. In addition, the extra weight can impair handling.

Avoid modifying your **GAS GAS** with non-original accessories and do not remove the original elements, these changes could affect the stability and handling, making the vehicle dangerous or illegal. The use of original spare parts and accessories or parts approved by **GAS GAS** is recommended. It is an essential condition for maintaining the warranty.

Your **GAS GAS** has been designed for off-road use, it has not been designed for long journeys on the road or motorway. Such use may result in damage to the engine due to the high revolutions and the tires are not suitable for use on paved surfaces. It has not been designed for urban use either. Long stops at traffic lights in the city could cause engine overheating.

Keep your **GAS GAS** in good condition. To avoid any problems, inspect your motorcycle before every use, and perform all maintenance as recommended in this manual. After a fall, check that the main elements have not been damaged. Riding a motorcycle in poor condition can cause an accident with serious injuries and even death.



DANGER


The exhaust pipe and other elements reach high temperatures during use and take time to cool down once the engine has been turned off. Avoid handling or touching anything during this period. The use of shorts is not recommended, since it can cause burns to the legs.



DANGER

Avoid wearing loose clothing that could get caught on parts of the vehicle or the surroundings. Although total safety is impossible, the use of adequate equipment reduces the possibility and/or severity of injuries.


Location of components EC 2T 200 / 300 cc



* An image taken from the ECRANGER 2T 300cc

Número	Nombre	Número	Nombre
1	Front reflectors	11	Licence plate holder with rear light, position, intermittent and rear reflector
2	Headlight position, long and short beam	12	Front brake disc
3	Front turn signals	13	Front brake calliper
4	Rear-view mirrors	14	Front fork
5	Overflow pipe	15	Starter
6	Fuel tank	16	Gear shift pedal
7	Fuel valve	17	Secondary exhaust
8	Air filter	18	Carburettor
9	Side stand	19	Chain
10	Chain guard	20	Chain guide


Location of components EC 2T 200 / 300 cc




* An image taken from the ECRANGER 2T 300cc

Number	Name	Number	Name
21	Muffler	30	Suspension linkage
22	Rear brake fluid tank	31	Footpegs
23	Seat	32	Rear brake pedal
24	Rear shock absorber gas tank	33	Centrifugal regulation
26	VIN chassis number	34	Crankcase guard
27	Radiator	35	Exhaust
28	Rear brake disc	36	Manufacturer's identification plate
29	Rear brake calliper		

Location of components



Number	Name	Number	Name
1	Choke lever	7	Fuel tank cap
2	Clutch fluid reservoir	8	Steering lock
3	Multifunction gauge	9	Stop
4	Front brake fluid tank	10	Throttle
5	Clutch lever	11	Front brake lever
6	Turn signals, lights, horn and starter		



Number	Name	Number	Name
1	Long and short-beam lights	4	Start
2	Horn	5	Stop
3	Turn signals		

Identification



Your **GAS GAS** has an identification plate (1) which details: manufacturer, chassis number, approval number and level of noise emissions.

The chassis number is also stamped on the right side of the steering column.

Steering lock



Your **GAS GAS** has a steering lock. It is located on the right side of the lower fork flange. To lock the steering:

1. Turn the handlebar all the way to the left.
2. Insert the key into the lock and turn it anti-clockwise $\frac{1}{8}$ back.
3. Press the key in.
4. Turn the key clockwise to its initial position and remove it. The closure must be sunk so that the lock is effective.

Specifications


ENGINE	Cycle		2-stroke	
	Number of cylinders		Mono-cylindrical	
	Refrigeration		Liquid cooled	
	Capacity		199.4 cc	299.3 cc
	Bore		62.5 mm	72.0 mm
	Stroke		65.0 mm	72.0 mm
	Carburettor		Dell'Orto PHBG 21 (Keihin PWKS 36 competition model)	
	Intake type		V-Force 4 Reed valve system	
	Lubrication system		Fuel mix	
	Starter system		Electric	
	Ignition system		Digital CDI-Euro 4	
	Pre-ignition set-up			
	Spark plug		DENSO W24ESR-U and NGK BR8EG	
	Distance between electrodes		0.7/0.8 mm	
TRANSMISSION	Primary reduction		3.31 (63/19)	
	Gearbox		6 speeds, cascade	
	Gear ratio	1 ^a	2.07 (14/29)	
		2 ^a	1.63 (16/26)	
		3 ^a	1.33 (18/24)	
		4 ^a	1.10 (20/22)	
		5 ^a	0.91 (23/21)	
		6 ^a	0.79 (24/19)	
	Secondary transmission		Per chain	
	Secondary reduction		4.16 (12/50) EC200 / 3.69 (13/48) EC300 Competition models only	3.30 (13/42) EC 300 3.40 (13/44) EC 200
	Chain		110 Links // 5/8 "x 1/4" with seals (112 links) competition model only	
	Type of clutch		Multi-disc oil bath with hydraulic drive	
	Clutch drive		Hydraulic	
	Lubrication	Medium	Oil	
		Capacity	900cc (New); 800cc (Replace)	
FRAME	Type		Central backbone frame in 25 CrMo 4 steel, aluminium alloy subframe	
	Measurements of tires and rims	Front	Excel 1.6 x 21 - 90/90 - 21	
		Rear	Excel 2.15 x 18 // 120/90 - 18	
	Tire pressure	Front	1.0 bar	
		Rear	1.0 bar	
	Suspension	Front	KYB fork ø46 mm, open cartridge, with regulation and compression and rebound	
		Rear	Progressive system with KYB single shock absorber with adjustable high and low speed compression and rebound	
	Suspension travel	Front	270mm (KYB)	
		Rear	119 mm (KYB)	

Specifications


			200	300	
FRAME	Front fork oil volume	KYB	560 ml. (quantity)		
	Brakes	Front	Disc, with Braktec 2-piston floating calliper		
		Rear	Disc, with Braktec 1-piston floating calliper		
	Brake discs	Front	NG wave Ø260 mm disc		
		Rear	NG wave Ø220 mm disc		
DIMENSIONS	Total height		1215 mm		
	Total length		2285 mm		
	Seat height		925 mm		
	Ground clearance		320 mm		
	Overall width		825 mm		
	Wheelbase		1475 mm		
	Dry weight		108 kg		
	Fuel tank capacity		9.8 l		
FLUIDS		RECOMMENDED			
	Fuel		Lead free (minimum RON 98)		
	Recommended Fuel	E5 E10	Gasoline with a content of 10% ethanol		
	Oil mixture (JASO FC)	NILS DUO SYNT S 27	100% synthetic oil at 2% (50:1)		
			Semi-synthetic oil at 2% (50:1)		
			Mineral oil at 3% (32:1)		
	Coolant ²	NILS POLAR PLUS	Antifreeze mixture at 30%		
	Brake fluid	NILS BRAKE FLUID DOT-4	DOT-4		
	Clutch fluid pump	NILS FOR CLUTCH COMMAND	Mineral oil		
	Transmission oil	NILS FOR GEAR 10W40	5W40 / 10W40 API SF or SG		
Fork oil	KYB	KYB Fork oil 01M			
CARBURATION	Competition ⁴	Type of carburettor	Keihin PWKS 36	Keihin PWKS 36	
		Main jet		185	160
		Idle jet		45	35
		Needle		NOZI	N1EF
		Needle position		3rd from above	
		Throttle valve		6	7
		Air screw		1 and 1/2 turns from closed	

(2) Cold countries should adjust the coolant to their temperature.

(4) Exclusive use in closed circuit.



Electric diagram for 200 / 300 cc models







Table of tightening torques

EC 2T 200 / 300 CC - TIGHTENING TORQUES				
ENGINE		Measure	Torque (Nm)	
NUT	Engine axles	M10	60	
HANDLEBAR		Measure	Torque (Nm)	
SCREW	Lower handlebar flange	M10	40	
SCREW	Upper handlebar flange	M8	25	
SCREW	Clutch	M6	10	
FRAME		Measure	Torque (Nm)	
SCREW	Crankcase guard	M6	10	
SCREW	Left-hand side protector	M6	10	
SCREW	Tie Rod Cylinder Head	M8	20	
SUBFRAME		Measure	Torque (Nm)	
SCREW	Upper subframe	M8	25	Loctite® 243™
SCREW	Lower subframe	M8	25	Loctite® 243™
FORK		Measure	Torque (Nm)	
SCREW	Fork protector - Guided hose	M6 (pl)	8	
SCREW	Fork protector - Foot	M6	8	
SCREW	Foot fork	M8	15	
SCREW	Front axle	M24	35	
SCREW	Front brake calliper	M8	25	Loctite® 243™
SCREW	Upper flange	M7	15	
SCREW	Lower flange	M7	12	
TANK		Measure	Torque (Nm)	
SCREW	Tank-Silentblock-Chassis	M6	10	
REAR SHOCK ABSORBER		Measure	Torque (Nm)	
SCREW	Upper shock absorber	M12	60	Loctite® 243™
SCREW	Lower shock absorber	M12	50	
LINK		Measure	Torque (Nm)	
NUT	Tie-rod - Chassis	M12	80	Loctite® 243™
NUT	Tie-rod - Rocker arm	M12	80	Loctite® 243™
NUT	Rocker arm - Swinging arm	M12	80	Loctite® 243™
SWINGING ARM		Measure	Torque (Nm)	
NUT	Swinging arm nut	M14	80	
SCREW	Shoe chain - Protector	M6	10	
SCREW	Lower shoe chain - Chassis	M8	25	Loctite® 243™
SCREW	Chain guide	M6	10	
NUT	Rear wheel axle nut	M20	100	
EXHAUST		Measure	Torque (Nm)	
SCREW	Muffler - Upper	M6	12	
SCREW	Muffler - Lower	M6	12	
SCREW	Silentblock exhaust	M6	12	
PLASTIC		Measure	Torque (Nm)	
SCREW	Front fender	M6	12	
SCREW	Rear fender	M6	12	
SCREW	Inf. side plates to radiator	M6	8	
SCREW	Tank and plates	M6 (pl)	6	
SCREW	Right-hand valve cover	M6	12	
SCREW	Electrical components box	M6 (pl)	6	
CENTRE STAND		Measure	Torque (Nm)	
SCREW	Center stand	M8	25	Loctite® 243™
REAR BRAKE		Measure	Torque (Nm)	
SCREW	Brake pedal	M8	20	
SCREW	Rear brake pump	M6	12	Loctite® 243™
ELECTRICITY		Measure	Torque (Nm)	
SCREW	Battery	M5	2.5	
GEAR SHIFT PEDAL		Measure	Torque (Nm)	
SCREW	Gear shift pedal	M6	12	Loctite® 243™
KICK-STARTER		Measure	Torque (Nm)	
SCREW	Kick-starter	M6	12	
SEAT		Measure	Torque (Nm)	
SCREW	Seat	M6	10	

Table of tightening torques

ENGINE



ENGINE	200 / 300 cc			
	No.	Part name	Measure	Torque (Nm)
	1	Valve cover bolts	M5x15	8
	2	Crankcase bolt	M6x25	12
	3	Gear shift pedal bolt	M6x12	14

Table of tightening torques




Table of tightening torques

			200 / 300cc		
			Measure	Torque (Nm)	
ENGINE	No.	Part name			
	1	Cylinder nut	M10	40	
	2	Clutch cover bolt	M6	12	
	3	Water pump drain bolt	M6	8	
	4	Spark plug	-	25	
	5	Cylinder head bolt	M8	27	
	6	Reed block bolt	M6	12	
	7	Ignition cover bolt	M6	8	
	8	Engine drain plug	M12	15	
	9	Oil fill bolt	M12	15	
	-	Ratchet plate bolt	M6	8	
	-	Stator bolts	M5	8	
	-	Ignition motor coil bolt	M10	60	
	-	Selector spring fixing bolt	M8	15	
	-	Primary nut	M20	80	
	-	Clutch spring bolts	M6	10	
	-	Valve control support bolt	M5	8	Loctite® 243™
	-	Clutch hub nut	M18	80	

Multifunction gauge (EC models only)



SWITCHED ON

When the motorcycle is started, the display panel is activated and remains on.

The dashboard will display the normal mode and will be on for 30 seconds if no speed pulse is generated.

If one or both buttons are pressed, the dashboard will display normal mode and will last 30 seconds if no button is pressed.

SPEED

The speed or speed units are permanently displayed in Km/h or mph with a range of 0 to 199 in both cases.

ODOMETER

- To display the breaking-in time or Km press SET < 2 seconds.
- To change units press SET > 10 seconds.
- To display the total press MODE < 2 seconds
Route A - Route B - Total.
- To enter the clock mode press MODE & SET > 2 seconds.
- To enter the wheel length mode press MODE > 10 seconds.

CLOCK

Format:

If the units are in Km. ----> 24h.

If the units are in mi. ----> 12h.

- To increase the hour digits press MODE < 2 seconds.
- To increase the hour digits quickly press MODE > 2 seconds.
- To increase the minute digits press SET < 2 seconds.
- To increase the minute digits quickly press SET > 2 seconds.
- To exit the clock mode and save the values press MODE & ET > 2 seconds.
- Pressing NO ACTION > 10 seconds will exit without saving changes.

ROUTE A and ROUTE B

- Press MODE < 2 seconds to display the dashboard.
- Press SET < 2 seconds to display the breaking-in time or Km.
- Press SET > 2 seconds to reset.

CONFIGURATION FOR WHEEL LENGTH

- To change the wheel from 2100 - 1811 press MODE < 2 seconds.
- To exit the wheel length mode and save the value press MODE & SET > 2 seconds.
- To exit automatically without saving changes, press NO ACTION > 10 seconds.

Homologation

NOTE: This chapter is not valid for XC models.

The vehicle you have just purchased is a vehicle approved under EU directives and complies with all approval requirements.


The mandatory approval components for riding on public roads and for passing technical inspections at MOT garages are, among others, those detailed below.


The components of approval, among other requirements, are identified with a determined and registered marking

List of components	Quantity/bike
Manufacturer's identification plate	1
Catalysed exhaust	1
Homologated front and rear sprockets	1
Carburettor Dell'Orto PHBG21	1
Fuel overflow assembly	1
Front and rear turn signals	4
Homologated licence plate holder + light + reflector	1 / 1 / 1
Front reflectors	2
Speedometer	1
Horn	1
Rear-view mirror	2
Steering lock	1
Secondary air valve	1
Air filter restriction	1
Throttle opening limiter	1
Homologated fuel and starter cable	1 / 1
Blow-by tube assembly	1

Each of the approved components must be part of the vehicle and in case of breakage, loss or malfunction the owner is advised to consult his official **GAS GAS** dealer to correct the problem.


This page has been left blank intentionally.





OPERATING INSTRUCTIONS

Starting procedure



To start your GAS GAS with the kick-starter follow the following steps:

1. Open the fuel tank tap.
2. Release the kick-starter.
3. Give two strong fuel strokes.
4. Engage the choke lever (1).
5. Operate the kick-starter vigorously.

NOTE: With the engine at operating temperature it is not necessary to use the choke lever.

To start your GAS GAS with the electric starter perform the following steps:

1. Open the fuel tank tap.
2. Turn the ignition key (2).
3. Give two strong fuel strokes.
4. Engage the choke lever (1).
5. Engage the clutch lever.
6. Press the start button.

NOTE: With the engine at operating temperature it is not necessary to use the choke lever.

Breaking-in

It is important to carry out the breaking-in phase, by doing this you will ensure the duration and correct function of your engine in the long term. The intervals to be performed are the following:

1. From 0 to 200 Km: Riding at between 50% and 75% load (throttle opening), alternately, without continued use at 75% load.
2. From 200 to 300 Km: Riding the same but reaching on occasion, without keeping it more than 5 ~ 10 seconds, at 100% load.
3. From 300 to 400 Km: Riding a 75% to 100% load, alternatively, without maintaining the load stop.
4. From 400 km, increase the requirement with some escalation around 60 ~ 80 km, until reaching its full performance.



DANGER


Reckless acceleration can cause problems in the engine. Take care that you use the skills and techniques necessary in riding the motorcycle.

Daily inspection before riding



Prior to each use of your **GAS GAS** motorcycle it is necessary to carry out the following checks:

Is there enough fuel? Open the fuel cap and, by moving the motorcycle sideways with the handlebar, you will see and hear the fuel, so you will know the approximate contents.



Is the fuel tap open? The fuel tap (1) has three positions: open: ON (tap down), closed: OFF (horizontal tap to the right side of the motorcycle) and reserve. RES (horizontal tap to the left side of the motorcycle). If the tap is in the OFF position there is no fuel to the carburettor, the motorcycle will not run, this position is used only when the engine is stopped. If you can see that there is little fuel in the tank, it should be started with the tap in the RES position, and go immediately to refuel. If everything is correct you must always use the tap in the ON position.

NOTE: Always turn off the fuel tap (OFF position) when the engine stops.



What is the oil level in the engine? Check through the oil sight glass (2) that the level is suitable, if necessary, add more oil.



What is the coolant level? By removing the filler cap from the radiator, the coolant level can be checked. This should be just below the metal rim (3), if necessary, add more coolant.




DANGER

Do not open the plug while the engine is hot, you risk serious burns.

Daily inspection before riding



1



2

What are the levels of brake fluid? The brake fluid tanks, one for each brake, have a sight glass (1 and 2) for checking their level.



DANGER

If the brake fluid level is close to half the sight glass on both the front and rear brakes, check the thickness of the brake pads and ensure that they are not within their limits of use. If the thickness is correct fill up the brake fluid and make sure there are no leaks, in case of any doubt go immediately to your official **GAS GAS** dealer, they know what should be done in each case. This can affect your safety.



What is the clutch fluid level? It should be checked as follows: motorcycle on its stand and handlebar turned to the right, in this position, unlatch the tank lid together with its rubber bellows (beware of DIRT, it is necessary to have a clean space in which to leave the disassembled parts), slowly turn the handlebar to the left until the liquid level is parallel to the top edge of your tank. The average level should not be more than 6~8 mm from the top edge of the tank. If the level is lower than that mentioned above, fill it up. In case of doubt or anomaly go to your official **GAS GAS** service centre.


Do the brake discs look OK? Visually you can see important scratches, cracks, excessive wear, etc.



DANGER


Check that the thickness of the discs is 3 mm at the front and at least 3.5 mm at the rear. Go immediately to your official **GAS GAS** service centre if you don't know what to do in each case. This can affect your safety. Do not ride the motorcycle.

Daily inspection before riding



Are the front and rear brake pads in good condition? Visually we can see the thickness of lining (1) that they have left, we know if they are in working condition or if they must be changed quickly, the thickness of the lining should not be less than 1 mm.

Are the controls OK? Front brake lever, rear brake pedal, clutch lever, gear shift pedal, starter lever, light controls, stop, horn and indicators, accelerator, kick-starter. All these command and control elements, have a characteristic operation and feel, any changes may indicate an anomaly or deterioration, you know your motorcycle best, if you feel any changes go immediately to your official **GAS GAS** service centre. The official **GAS GAS** service centre will be happy to assist you and to ensure your safety.



Does the side stand feel OK? The stand is a part of the motorcycle that often causes problems, including safety problems, because it is a part that receives severe treatment. If you notice that it feels strange or difficulty in its redeployment, you must first thoroughly clean the whole assembly and check the tightening of the fastening and the condition of the springs. If the abnormal behaviour continues, you should go to your official **GAS GAS** service centre immediately, for your safety.



Does it seem to have the correct tire pressure? If in doubt ALWAYS check the pressure level. If the problem persists, or is repeated, it may be due to the presence of leaks, consult your official **GAS GAS** dealer.

Daily inspection before riding



Are the spokes of the wheels properly tensioned? By pressing them with your fingers you can notice any possible lack of tension. In case of excessive looseness in any of them, it is necessary to check them all and on both wheels, it is a job for experts, we recommend that you go to your official **GAS GAS** service centre.



Is the condition of the chain and its tension correct? If it is necessary to tighten the chain, or if it needs to be tightened too frequent or if you see any signs of wear on the front sprocket, rear sprocket, chain guides or chain protector, you should go to your official **GAS GAS** service centre, this affects your safety .

Is the seat correctly set? This is a vital point for your safety, if you have any doubts about this, go to your official **GAS GAS** service centre.

Is there any element that runs the risk of detachment? Fenders, side covers, fuel tank, dust covers, etc. If so, you should try to attach it or take it off completely to avoid it falling off, for your safety. Contact your **GAS GAS** dealer to repair it.



Is there any air to be purged from the front suspension? (1) If your model requires it, it must be done properly, otherwise it may be a problem for your safety and for the longevity of your front suspension.

1

Daily inspection before riding

Are there any leaks? Visually check for possible leaks, assessing them based on their location, amount and product leaked (pay attention to the danger of fire). Always go to your official **GAS GAS** dealer as quickly as possible.



DANGER

These controls are really very quick to carry out, it is a matter of habit, the user knows the use to which the motorcycle has been subjected in its last use and knows where it should this control be sharpened. Respect for this set of controls means greater safety for the user and, certainly, better and more economical maintenance of your motorcycle.

Cleaning

To clean your **GAS GAS** follow these steps:

1. Cover the exhaust system to prevent water from entering.
2. Cover the steering lock with a piece of duct tape.
3. Remove the mud and dirt with a low pressure water jet.
4. Clean the areas that are particularly dirty with a special cleaner for motorcycles.
5. Rinse with a jet of water at low pressure.
6. Let the motorcycle drain naturally.
7. Take a short ride on the motorcycle until the engine reaches its operating temperature.
8. Lubricate the chain and all other elements that need it (see Maintenance section).



WARNING

Never clean the vehicle using high pressure equipment. Avoid direct contact with multifunction gauge, coil, pipe plug, carburettor, switches, levers or any other electrical element.

Storage

When you have to store your motorcycle for a period of time you should:

- Thoroughly clean the motorcycle.
- Start the engine for about 5 minutes to warm up the transmission oil and then empty it (see Maintenance).
- Put in new transmission oil.
- Empty the fuel tank (if left for a long time the petrol deteriorates).
- Lubricate the chain and all cables.
- Put oil on all unpainted metal surfaces to prevent rust, avoiding getting oil on the brakes and rubber parts.
- Place the motorcycle in such a way that the two wheels do not touch the ground (if this is not possible put cardboard under the wheels).
- Cover the motorcycle to protect it from dust and dirt.

To put it into operation after storage:

- Remove the plastic bag from the exhaust pipe.
- Tighten the spark plug.
- Fill up the fuel tank.
- Check the points in the section "Daily inspection before riding".
- General lubrication.

OBD Operation


The OBD (On Board Diagnostic) system incorporates a MIL indicator light to indicate a malfunction.

When the motorcycle is started, the MIL (Malfunction Indicator Light) light is on.

If there is no error, the MIL turns off after 5 seconds.

If the OBD system detects an error, the MIL light stays on permanently.

It will turn off if it is started 3 consecutive times exceeding 2,000 rpm, if no error is detected.



It can be connected to the OBD system using a diagnostics machine compatible with the ISO 15765-4 CAN protocol. To connect the 4-way socket of the motorcycle's electrical system to the diagnostics machine (18-pin JAE connector), it is necessary to use an interface cable, which can be purchased from GG's spare parts department under reference EM10225TT-CLR-1.

The 4-way socket is under the seat.



To connect the *Creader VI+* scan tool (or similar) the protection must be removed from the connector.



When the scan tool is connected, it turns on and the start screen appears connecting to the ISO 15765-4 CAN protocol that our OBD system has.

If the system detects an historical error, the MIL stays on permanently.

Also, if you use the *Creader VI* scan tool, you can see in Monitor Status the information MIL status ON. (With the key light in red at the top).

You can cancel the error if you go to Diagnosis Menu - Erase error. If you return to the Monitor Status screen, the MIL Status is OFF and, at the top, the green light appears and the red key light turns off. And, at the same time, the MIL turns off on the switch.

On the scan tool, the following information can be viewed:

- Current RPM, maximums.
- Time in seconds that the engine is running.
- Minutes running with the MIL on.
- Total minutes of engine running. And the ISO 15031 Diagnostic Trouble Codes (DTC):

P0350 - Ignition coil malfunction.

P0315 - Ignition pick-up fault

It is possible to access the DTC and clear all historical errors.

This page has been left blank intentionally.

MAINTENANCE

Maintenance table

The maintenance requirements set out in this table are simple and necessary for the good maintenance of your motorcycle. *

Element	Check / Inspect	Adjust	Replace / Change	Clean	Grease / Lubricate
1.-Clutch	10 hours	20 hours	When needed	-	10 hours
2.-Clutch discs	30 hours	When needed	When needed	-	-
3.-Throttle cable	10 hours	10 hours	-	-	10 hours
4.-Spark plug	-	-	20 hours	10 hours	-
5.-Air filter	0.5 hours	-	When damaged	When needed	-
6.-Carburettor	20 hours	When needed	-	-	-
7.-Transmission oil	-	-	20 hours	-	-
8.-Piston and ring	-20	-	50 hours	-	-
9.-Cylinder head, cylinder and exhaust valve	-	-	When needed	20 hours	-
10.-Exhaust system	-	-	When needed	-	-
11.-Silencer fibre	-	20 hours	30 hours	-	-
12.-Connecting rod and bearings	80 hours	-	120 hours	-	-
13.-Kick-starter and gear shift pedal	-	-	-	-	10 hours
14.-Rubber gasket exhaust/silencer	10 hours	-	When needed	-	-
15.-Crankshaft bearings	80 hours	-	120 h or When needed	-	-
16.-Coolant	-	-	30 hours	-	-
17.-Radiator tube and connections	10 hours	-	40 hours	-	-
18.-Brakes adjustment	20 hours	-	When needed	-	-
19.-Brakes wear	30 hours	-	When needed	-	-
20.-Brake fluid	-	-	Every 2 years	-	-
21.-Brake fluid level	10 hours	20 hours	When needed	-	-
22.-Brake pump piston and dust cover	-	-	Every 2 years	-	-
23.-Brake piston and dust cover	-	-	Every 2 years	-	-
24.-Brake hose	-	-	Every 4 years	-	-
25.-Spokes and front wheel	-	10 hours	When needed Use Loctite 243 for the spokes	-	-
26.-Spokes and rear wheel	-	10 hours	When needed Use Loctite 243 for the spokes	-	-
27.-Chain guide	-	-	-	-	20 hours
28.-Chain guide wear	20 hours	-	-	-	-
29.-Chain guide shoe	20 hours	-	When needed	-	-
30.-Front Suspension	10 hours	When needed	When needed	When needed	-
31.-Front suspension oil	-	-	30 hours	-	-
32.-Bolts, nuts and fasteners	10 hours	20 hours	When needed	-	-
33.-Petrol tube	20 hours	-	When needed	-	-
34.-Fuel system	-	-	-	When needed	-
35.-Steering head adjustment	10 hours	-	-	-	-
36.-General lubrication	-	-	-	-	20 hours
37.-Steering bearing	-	-	-	-	30 hours
38.-Wheel bearing	30 hours	-	When needed	-	-
39.-Swingarm and linkage	20 hours	-	When needed	-	20 hours
40.-Rear suspension	Every 2 years	When needed	When needed	-	-
41.-Chain	-	10 hours	When needed	-	-
42.-Tires	5 hours	-	When needed	-	-
43.-Battery charge	12 hours slow charge	-	-	-	-

* If the vehicle is used in competition, maintenance intervals should be shortened

Maintenance



1-CLUTCH

The clutch lever can be adjusted to your comfort.

To regulate it, perform the following:

- With the wheel (1) adjust the distance from the lever to the handlebar depending on the comfort of the rider.

The assembly is designed so that the position of the lever is not altered in operation.



DANGER


- This model uses NILS FOR CLUTCH COMMAND mineral oil for the clutch hydraulic circuit.

2-CLUTCH DISCS

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

3-THROTTLE CABLE

- Check that the throttle control (1) turns smoothly.
- Check that the control has a play of 2 ~ 3 mm.
- If the play is incorrect, loosen the locking nut (2) at the end of the throttle cable, turn the adjuster (3) to obtain optimum play.
- Tighten locking nut again.
- If the free play cannot be established by adjusting the cable, remove the cable shield in the carburettor, tighten it with a tensioner at the end of the cable, tighten the locking nut and reinstall the guard.



4-SPARK PLUG


The standard spark plug (Denso W24ESR-U or NGK BR8EG) must be tightened to 25 Nm.

The spark plug has to be removed periodically to check the distance between electrodes (0.7 ~ 0.8 mm). If the spark plug contains oil or cinder, wipe it with a wire brush or similar. Measure the distance between electrodes with a gauge and adjust in case it is incorrect bending the outer electrode. If the spark plug electrodes are rusty, damaged, or the insulation is broken, replace the spark plug.

NOTE: Inspect every 10 hours and replace every 20 hours.

To find the correct temperature at which the spark plug should work, remove it and examine the ceramic insulator around the electrode. If the ceramic has a light brown colour, the temperature of the spark plug matches that of the engine. If the ceramic is white, the spark plug should be replaced by a colder one. If it is black you must replace it with a warmer one.

NOTE: If engine performance drops, replace spark plug to regain normal performance.



Maintenance

5.-AIR FILTER

Removing the filter

To access the air filter, remove the left side cover



1. Remove the left side cover by pulling it by its three ends.



2. Remove the filter handle.



3. Remove the air filter.



Maintenance



①

Cleaning the filter

1. Clean inside the filter box with a damp cloth (1).
2. Remove the cage (2) from the air filter (3).
3. Clean the filter in a liquid bath for cleaning filters using a soft brush.
4. Squeeze and dry with a clean cloth. Do not touch the filter or ventilate it, because it can become damaged.
5. Install the filter in the cage and cover the filter lip (4) with a thick layer of grease to ensure the closure and prevent dirt from getting in.



DANGER

A clogged air filter allows dirt to enter the engine causing excessive wear and damage.


Inspect it without fail, before and after each race or session. Clean if necessary.

Clean the filter in a ventilated area and make sure there are no sparks or flames near the work place (include a powerful light bulb). Do not use petrol to clean the filter as this may cause an explosion.




WARNING

- Inspect the filter for damage. If it is damaged replace it or dirt will get into the carburettor.
- Grease all air filter connections and screws and inlets.



②

③



④

Maintenance

6.-CARBURETTOR

Idle adjustment

This is carried out by adjusting the air screw (1) and the idle screw (2).

1. Turn the air screw clockwise until it reaches the top of its travel and open 1 turn and 1/4.
2. Heat the engine, turn the idle screw, adjust the idle speed. If there are no references, turn the screw until the engine stops.
3. Tighten the idle screw slightly.
4. Accelerate and decelerate a few times to ensure that the idle does not change. Readjust if necessary.






DANGER

Riding with a damaged throttle cable can be dangerous.

Check that the throttle cable has a minimum clearance of 3mm on the control.

With the engine at idle, turn the handlebar in both directions. If the engine is stalled or accelerated with the handlebar movement, the throttle cable has been improperly adjusted or is in poor condition. Make sure to correct it before riding the bike.



7.-TRANSMISSION OIL

For the transmission and clutch to work properly, keep the transmission oil at the optimum level and replace it periodically. A motorcycle with insufficient, deteriorated or contaminated transmission oil can accelerate wear and damage transmission.

Checking the oil level

1. If the bike has been used wait a few minutes.
2. Check the oil level using the level indicator on the lower right side of the engine (1).
3. The oil level must be between the maximum and the minimum.
4. If the level is too high, remove the excess through the drain plug (2).
5. If the level is low, add the required amount of oil by opening the cap. Use the same type and brand of oil as you already had in the engine.

Transmission oil

Recommended oil: NILS Gear lubricant & high performance clutch.

SAE 10W40 / 5W40

Capacity: 900 cc

NOTE: To achieve the proper engine oil temperature and to accurately measure the oil level, the engine must have cooled down completely, and then it must have been heated again for a few minutes at normal operating temperature.

Maintenance



1

Transmission oil change

Transmission oil should be changed periodically to ensure engine life.

1. Heat the engine for 5 minutes for the oil to raise any sediment.
2. Stop the engine and place a container under the engine.
3. Remove the oil drain screw (see Checking the oil level) and put the motorcycle in the use position to allow all oil to escape.
4. Remove the fill plug (1) to ensure a better draining.
5. Thoroughly clean the magnet of the drain screw.
6. Screw in the oil drain with its O-ring, and tighten it to 20 Nm.
7. Remove the fill plug (see Checking the oil level) and pour new transmission oil in.
8. Check the oil level, after operating the kick-starter 3 or 4 times.
9. Screw the oil filler cap.



1

2

8.-PISTON AND RING

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

9. CYLINDER HEAD, CYLINDER AND EXHAUST VALVE

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

10.-EXHAUST SYSTEM

The exhaust and muffler reduce noise and conduct gases away from the rider.

If the exhaust is damaged, rusted, hit or cracked, replace it with a new one. Replace the muffler fibre if noise becomes too high or the engine performance decreases.

Exhaust cleaning

For the cleaning of the exhaust pipe, please contact your official **GAS GAS** service centre.

Replacing the muffler

1. Remove the clamp screw from the muffler (1).
2. Remove the lower clamp screw (2) from the muffler (3) and remove it by pulling back.
3. Disconnect the muffler from the joint (arrow)
4. Replace the muffler and reassemble the assembly.



Maintenance




11.-MUFFLER FIBRE

The muffler of your **GAS GAS** is an absorption muffler. The absorbent element is the muffler fibre. If there is an increase in exhaust noise, the muffler fibre must be replaced.

Replacing the muffler fibre

Once the muffler is removed, (see Replacing the muffler). Remove the 4 screws (1).

1. Remove the inside of the muffler.
2. Replace the muffler fibre (2) by winding it to the inner tube.
3. Insert the fibre around the exhaust pipe (3) into the rear end of the muffler.
4. Reassemble the assembly.



Maintenance

12.-CONNECTING ROD AND BEARINGS

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

13.-KICK-STARTER AND GEAR SHIFT PEDAL

Lubricate the moving and articulated parts with oil or grease, excessive lubrication can cause your boots to slip on the pedals.

14.-RUBBER GASKET EXHAUST/SILENCER

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

15.-MOTOR BEARINGS

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

16.-COOLANT

The coolant absorbs excessive heat from the engine and transfers it to the air through the radiator. If the fluid level drops, the engine overheats and can severely damage it. Check your fluid level every day before riding your **GAS GAS**.

To protect the aluminium parts of the cooling system (engine and radiator) from rust and corrosion, use chemical inhibitors in the essence of coolant. If an anti-corrosive liquid were not used, after a while the radiator would rust. This would obstruct the cooling tubes.

NOTE: Initially, a permanent-type antifreeze is used at the factory. It is green, contains 30% ethylene glycol and has a freezing point of -18°C.



DANGER

Chemical liquids are harmful to the human body. Follow the manufacturer's instructions.



WARNING


Use of incorrect liquid solutions can cause damage to the engine and cooling system.

Use coolant with anti-corrosive specific for aluminium engines and radiators according to the manufacturer's instructions.

Coolant level

1. Put the motorcycle in the use position.
2. Unscrew the radiator cap (1) anticlockwise and wait a few seconds for the vapours to escape. Then tighten and turn in the same direction to complete the removal of the plug.
3. Check the coolant level. The liquid should be just below the rubber stopper of the cap.
4. If the liquid level is low, add the required amount through the fill opening.

Recommended liquid: NILS POLAR PLUS



Maintenance



(2)

Change coolant

It must be changed periodically for a long engine life.

1. Wait for the engine to cool completely.
2. Put the motorcycle in the use position.
3. Remove the radiator cap.
4. Place a container under the drain screw (2) which is located on the underside of the water pump cover. Drain the radiator and engine fluid by unscrewing.
5. Fill the radiator to the rim of the cap and fit the radiator cap.
6. Check the cooling system for leaks.
7. Start the engine, warm it up and finally stop it.
8. Check the coolant level when the engine cools down. Add liquid to the stopper if necessary.



DANGER

To avoid burns do not remove the radiator cap or try to change the liquid when the engine is still hot. Wait until it cools down.



DANGER

If liquid falls on the tires it makes them more slippery and can cause an accident. Immediately clean any liquid that may fall into the chassis, engine or wheels.

Inspect the old liquid. White spots on the liquid will mean that the aluminium parts of the cooling system are corroded. If the liquid is brown it is because the steel or iron parts of the system are rusted. In both cases clean the system.






WARNING

Tighten the drain screw on the water pump to 9 Nm. Replace the gaskets with new ones.

Check for any damage, loss or lack of seals in the cooling system.

Cold countries should adjust the antifreeze capacity to their minimum temperature with a margin of -5°C.

Maintenance



17.-RADIATOR TUBE AND CONNECTIONS

Radiator tubes

Check that the radiator tubes are not cut or damaged and that the connections are not leaking.

Radiator

Check that the radiator fins (1) are not obstructed (insects or mud). Clean the obstructions with a low pressure water jet.



WARNING

Using high pressure water can damage radiator fins and reduce their effectiveness.

Do not obstruct or divert the air intake to the radiator by installing unauthorized accessories. Interference in the radiator can overheat and damage the engine.

18.-BRAKES ADJUSTMENT

Front brake lever:

Adjust the brake lever (1) until you feel comfortable. To adjust it, loosen the nut (2). After adjusting it, tighten securely. Check that the brake responds correctly.

Rear brake pedal:

When the brake pedal (3) is in the rest position you should have a play of 5-7 mm. Check the brake for correct response and do not rub it.



DANGER

If the brake pedal or brake lever feels spongy when actuated, it may be because there is air in the pump or circuit corresponding to each brake, or that a component of the corresponding brake system is in poor condition.

Since it is dangerous to ride in these conditions check the brakes immediately, for this we recommend you go to your official **GAS GAS** service centre.

Maintenance

19.-BRAKES WEAR

If the thickness of any of the brake pads on the front or rear disc is less than 1mm, a complete change of the affected pad set must be carried out.



DANGER

Check that the thickness of the discs is at least 3 mm on the front and 3.5 mm on the rear.







WARNING

For this change we recommend that you go to your official **GAS GAS** service centre who, in addition, will check the possible wear of your brake discs.




Changing the front brake pads

To change the front brake pads, follow these steps:

1. Loosen the pin (1) and remove it.
2. Remove the pads (2)
3. Put a paper or cloth around the brake fluid tank to prevent it from falling. Open the cover by loosening the screws (3). **NOTE:** For better access it is recommended to loosen the screw (4) and turn the throttle assembly.
4. Remove the cover (5) ensuring that no brake fluid falls out of the tank.
5. Retract the two calliper pistons so as not to damage them.
6. Install the new pads.
7. Attach the pin.
8. Replace the cap of the tank.
9. Operate the brake lever several times until you get the proper feel.



Maintenance



Changing the rear brake pads

To change the rear brake pads follow these steps:

1. Loosen and remove the pin (1) (2).
2. Remove the pads (3).
3. Loosen and remove the cap (6) of the brake fluid tank.
4. Put a paper or cloth around the brake fluid tank to prevent it from falling.
5. Retract the calliper piston so as not to damage it.
6. Install the new brake pads
7. Attach the pin and its protector.
8. Replace the cap of the tank.
9. Operate the brake pedal several times until you get the proper feel.

Maintenance

20.-BRAKE FLUID

Inspect the brake fluid and replace it periodically. It must also be changed if it is contaminated with water or dirt.

Recommended liquid: NILS Brake Fluid DOT 4.




DANGER

Do not mix different types of brake fluid. The liquid used to fill or renew the circuit must meet the standard specified on the liquid tank of each circuit. Therefore, the rear brake must use DOT 4.

It should never change its specification, always adhere to the DOT 4 specification, it is not important that the brake fluid is of the same brand, but it is NECESSARY that it is of the same specification.

Do not use fluid from a container that is not sealed (unopened) at origin. NEVER use brake fluid from an unsealed container or, of course, brake fluid that has already been used.



21.-BRAKE FLUID LEVEL

The front (1) and rear (2) liquid tanks must be at least half full. If liquid is missing, it should be added.



WARNING

Do not pour brake fluid onto painted surfaces.



DANGER

Check for leaks.

Check for damage to brake hoses.



22.-BRAKE PUMP PISTON AND DUST COVER (FRONT AND REAR)

For this check, adjustment, or change, please contact your official GAS GAS service centre.

Maintenance

23.-CALLIPER PISTON AND DUST COVER (ALL CALLIPERS)

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

24.-BRAKE HOSES

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

25 AND 26.-SPOKES AND WHEELS

The spokes must be evenly tightened and must not have any play, making the tire off-centre, the other spokes would resent and could rupture.

Centring the wheel:

Place a dial indicator next to the rim (1) and turn the wheel to measure the axial centring.

Place the dial on the inside of the circumference of the rim (2), turn the wheel and the difference between the highest and the lowest amount is the centring.



If it is slightly off centre it can be corrected by loosening or tightening some spokes with the spindle tensioning wrench (3). If the tire is bent or curved it should be replaced.

NOTE: A welded area on the rim may show excessive de-centring. Ignore it when measuring the centring.



WARNING

Interventions on tires and spokes require the assistance of a specialist, so we recommend that you go to your official **GAS GAS** service centre.



27.-CHAIN GUIDE

Lubricate the chain guide (4) with the same product used to lubricate the chain.


28.-CHAIN GUIDE WEAR

Check the state of the inner faces of the chain guide, where the chain passes, depending on its state, it must be replaced.

29.- CHAIN GUIDE SHOE

Visually check the top and bottom of the chain shoe (5) on the swingarm (6). If it is worn or damaged, replace it.

Lubricate the chain guide with the same lubrication product as the chain.




Maintenance

30.-FRONT SUSPENSION

Front suspension air purge

To purge the air from the front suspension follow these steps:

1. Place the bike on an easel or stable support. The front fork must be fully extended.



Change of fork spring

In case you need to change the front fork spring, follow these steps:


1. Remove the bar from the suspension flanges.
2. Loosen the upper nut of the fork.
3. Remove the inner oil from the fork.
4. Loosen the lower nut of the fork.
5. Remove the inner cartridge.
6. Remove the spring.

Replace the spring and follow the steps in reverse order to assemble it.



WARNING

Make sure that the brake and clutch fluid tanks are always vertical, otherwise both systems must be bleed again.



Maintenance

31.-FRONT SUSPENSION OIL

Adjusting the oil volume

To adjust the oil volume you must first remove the spring, follow the steps described in "Change of fork spring".

Provide a graduated cylinder for liquids in which you must enter the indicated volume of recommended oil (in each bottle).

Slowly insert the oil from the graduated cylinder into the fork tube.

And to ensure the correct bleeding of the hydraulic push the rod gently and alternatively throughout its entire length (up and down), several times, until its stops.

Reassemble the fork cap assembly.

Scrupulously respect the fill volume, since on this depends the level of oil in the inside of the fork and its correct operation.

Recommended oil KYB 46: KYB 01M Oil for closed cartridge suspension. Oil volume: 350 ml.



32.-BOLTS, NUTS AND FASTENERS

Every day before using the bike, you should check that all nuts and bolts are tightened. Also check that the other fasteners are in place and in good condition.

33.-PETROL TUBE


If you observe a pinch (narrowing) in the pipe (1) in any location (usually in the petrol inlet to the carburettor and at the outlet of the petrol cock), or symptoms of cracking on the surface, it is imperative to change the petrol tube.



DANGER

Riding with a damaged petrol tube or simply starting the engine can result in a fire and consequently an accident (and corresponding injuries)

ALWAYS USE THE ORIGINAL PETROL TUBE, YOUR OFFICIAL **GAS GAS** SERVICE CENTRE WILL PROVIDE YOU WITH ONE.



Maintenance

34.-FUEL SYSTEM

Check the status of: The rubber of the tank cap, the tank cap, the tank breather tube and the tank.

35.-STEERING HEAD ADJUSTMENT

The steering should always be adjusted so that the handlebar rotates freely, but without play.

To check the steering adjustment, lift the bike off the ground, using a bracket under the chassis. Move the handlebar gently to each side, if when letting go of the handlebar it continues to move by itself, it means that the steering is not too tight. Squat down in front of the motorcycle, grip the lower part of the front fork (in the shaft), push and pull the fork (1). If there is play, the steering is too loose.

If the steering must be adjusted:

1. Stabilize the motorcycle with the stand or with a special bench.
2. Keep the front wheel from touching the ground.
3. Remove the handlebar by loosening the screws on the handlebar clamps (2) and removing the upper flanges.
4. Loosen the steering axle nut (3).
5. Turn the steering nut (4) with the special wrench to obtain a suitable adjustment.
6. Tighten the steering axle nut.
7. Recheck the steering and reset if necessary.
8. Install the disassembled parts.



1






2

4



3

Maintenance



36.-GENERAL LUBRICATION

Lubricate the parts shown, periodically or when the vehicle is wet, especially after using high-pressure water. Before lubricating each part, clean the rusted parts with antioxidant and remove any remaining grease, oil or dirt.

General lubrication

- Clutch lever (1).
- Front brake lever (2).
- Rear brake pedal (3).
- Rear brake pedal bearing (4).
- Gear shift lever (5).

Use a spray with a tube to lubricate with pressure.

Use grease inside the throttle cable.

Chain lubrication

This is necessary after riding on wet ground when the chain looks dry.

Its chain is made of seals, therefore you must use a specific lubricant for this type of chain. Your official **GAS GAS** service centre will gladly supply you with one.

37.-STEERING BEARING

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

38.-WHEEL BEARING

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

39.-SWINGARM AND LINKAGE

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

40.-REAR SUSPENSION

Shock absorber oil change

For this check, adjustment, or change, please contact your official **GAS GAS** service centre.

Maintenance


Removing the shock absorber

To remove the rear shock absorber from its location in the frame, follow these steps:

1. Stabilize the motorcycle with a central stand or with a special bench.
2. Keep the rear wheel from touching the ground with the help of a chock.
3. Loosen the exhaust clamping screws (1)



4. Disengage the exhaust springs (2)



5. Unscrew the shock absorber from the underside of the rocker arm (3).



6. Remove the screw and release the rocker arm (4).



Maintenance



7. Loosen the top screw of the shock absorber to the frame (5).



8. Remove the upper shock screw from the shock absorber to the frame (6)



9. Carefully remove the shock absorber from the right side of the motorcycle as illustrated in the photograph (7).

To reassemble the shock absorber on the motorcycle, follow the same steps in reverse order.

Maintenance

41.-CHAIN

The secondary transmission (chain, sprockets and guides) of your motorcycle supports undergoes hard work. It is also one of the most important assemblies for your SAFETY.

It requires constant maintenance and obviously, correct maintenance.

Chain tension

1. Motorcycle without load and with the side stand out: There should be a space of 30 ~ 36 mm. between the chain and the swingarm in the rear area of the chain guide. You can check with your fingers, but without overly forcing it.
2. Loosen the rear axle nut (1).
3. Find the point of maximum tension on the chain.
4. Using the nuts (2) of the tensioner, align the alignment of the chain on both ends of the swingarm using the notches on the swingarm and the lugs on the adjusters.
5. Tighten the nuts (2).
6. Tighten the nut (1).
7. Check again at the point of maximum tension and re-adjust it if necessary.

The chain tension is a constant check. The state of the chain itself must be checked visually, as well as the guide and the sprockets.

Usually, when a chain is overused, or stretched more than 2%, it should be replaced. Usually this is the right time to change the guide, the front and rear sprockets. This is for practical, economic and SAFETY reasons. A chain at the limit of its use has partially worn the teeth rear sprocket, guide, etc. If you install a new chain and do not change the other components, its life will be shortened by 40% and the already-deteriorated elements such as the front and rear sprocket will reach the end of their life quickly. In the medium and long term, the economic thing is to change the complete transmission kit at each chain change. Your official **GAS GAS** service centre will gladly supply you with one.

Lubrication: Its chain is of the type that has seals, this requires a special lubricant, use the same lubricant for the guide, the chain guide shoe and the front and rear sprocket.


NOTE: We recommend you always have the chain correctly lubricated, those chains that go dry, lubricated, dried, shorten their life and that of the components that surround them to a significant extent.

42.-TIRES


Check that the tires are not worn, cracked or damaged. Otherwise change for new tires of the characteristics shown in the technical sheet, with load index and minimum speed: front 41J, rear 52J. Also check that they are at the correct pressure.

Recommended pressure: 1,2 bar - (Standard Use)

**1 bar - (Competition Use)



Maintenance



43.-BATTERY CHARGE

The battery (HJTZ7S-FA) is maintenance free

6 Ah / 13-13.4 V / cca > 130A

Capacity / Voltage

Battery change

The battery is located under the seat, inside the battery case. To change it, perform the following steps:

1. Loosen the seat retaining screw (1) and remove it slightly by pulling it back.
2. Loosen and tighten the battery terminals.

Replace the battery with a new one and follow the steps in reverse order to assemble it.

Battery charger data

- Minimum voltage before starting the charging process 9v.
- When charging is complete, unplug the charger from the battery.
- Once charged, leave the battery between 1 to 2 hours before checking the voltage. If it is less than 10v, change it.
- Recharge the battery periodically.
- If you do not use the motorcycle, recharge every 3 months.



DANGER


Do not tamper with or attempt to open the battery, the electrolyte and gases are toxic and can cause serious injury.

Keep the battery out of the reach of children.

Keep the battery away from sources of heat, open flames and sparks.

Always store and charge the battery in a well-ventilated area.

Wear protective clothing and goggles.




SETTINGS

Introduction

The settings chapter is for a user with high mechanical knowledge and experience. Otherwise these adjustments must be carried out by your official **GAS GAS** service centre.

Carburetor setting * For XC model





OPENING OF THE THROTTLE VALVE AND INFLUENCES

The elements of the carburettor that alter the composition of the mixture depending on the opening of the gate (load or gas), depends on the opening of the same:


- Zone A: from 0 to $\frac{1}{8}$ of load (opening of the throttle). Its regulation depends on the idle screws and the regulation of the mixture and of the idle jet (low or minimum).
- Zone B: from $\frac{1}{8}$ to $\frac{1}{4}$ load. Influenced mainly by the height of the slide bezel.
- Zone C: from $\frac{1}{4}$ to $\frac{3}{4}$ load. The carburettor needle is responsible.
- Zone D: from $\frac{3}{4}$ to full load. The main jet is responsible for this.

IDLE JET AND MIXING SCREW

This controls the mixture from the closed position to $\frac{1}{8}$ load, but has little effect on the total opening. To adjust the mixture, the air screw can be turned to change the air flow, or change the idle jet so that more or less petrol goes in. First turn the air screw. Screwing it inwards enriches the mixture. The air screw must be turned from a fully closed position. Change with half turn increments. If turning the screw from 1 to 2.5 turns does not yield the desired result, change one step in the minimum idle jet (1) and tune with the air screw (2).



Carburetor setting * For XC model




CARBURETTOR NEEDLE

The needle and the needle diffuser together have an effect from 25% to 75% load. The needle moves inside the diffuser; when the needle narrows, from being cylindrical (1) to being conical (2), its position determines the amount of fuel admitted.

At the top of the needle there are five slots (3) where the clip is attached. This clip places the needle in the throttle valve and determines the relative position to the diffuser (that is why the mixture is enriched). Moving the clip up impoverishes the mixture. Change the position of the clip step by step (the cylindrical part of the needle affects the response of the throttle valve to its small openings).

The position of the clip is set by counting from the top position, which is the one that implies greater closure of fuel passage through the diffuser.



MAIN JET

It has a greater effect from 75% to 100% load. The number printed on the bottom of the jet (1) indicates the flow of petrol passing through the hole. A larger number corresponds to a larger hole, more petrol passes through.

NOTE: Never use the "jet gauge sets" that are on the market. Their use is INCORRECT. Always use new and unmanned jets (sealed in their bags) of original replacement.



DANGER


Petrol is extremely flammable and can be explosive under certain conditions. Whenever you handle the carburettor, stop the engine and do not smoke. Make sure the area is ventilated and there are no sparks or flames nearby (includes light from a bulb).

REFERENCE CARBURETION (COMPETITION ONLY)

	200cc	300cc
Main jet	185	175
Idle jet	45	42
Needle	NOZI	N1EF
Needle position	3rd from above	
Throttle valve	6	7
Air screw	1 and 1/2 turns from closed	

Carburetor setting * For XC model

CORRECTION FACTORS 250 / 300CC.



Needle position / Air screw opening

Correction factor	1.06 or higher	1.06 ~ 1.02	1.02 ~ 0.98	0.98 ~ 0.94	0.94 or less
Needle position	Lower clip 1 position	Same	Same	Same	Raise clip 1 position
Opening screw free	Tighten 1 turn	Tighten ½ turn	Same	Loosen ½ turn	Loosen 1 turn

NOTE: The values are indicative only

- Find the correction factor to adjust carburizing.
Example: 1000 m height and temperature of 35°C, correction 0.94.
- Using the correction factor, select the main jet.
Example: Factor 0.94, you must multiply the main jet by this number. Main jet = $175 \times 0.94 = 165$.
- Find your correction factor for the needle and air screw in the table and change the position of the clip and the air screw opening.
Example: Lift up the needle clip and turn the air screw one turn.



WARNING

To make corrections always take as a basis the competition carburetion. Do not make changes until you are sure they are needed. The specifications are based on the use of recommended petrol and oil.

Secondary transmission ratio

Secondary transmission ratio can be modified by changing the front and/or rear sprockets.

The available sizes of sprockets in GAS GAS are as follows.

Rear sprockets: 39, 40, 42, 44, 46, 47, 48, 49, 50, 51, 52.


Front sprockets: 12, 13.

If the ratio is shortened, your GAS GAS will lose top speed but gain in acceleration and at low speeds will be more manageable on difficult terrain.

NOTE: Pay attention to engine rpm.

If the ratio is extended, your GAS GAS will gain top speed but will lose acceleration and manageability at low speeds.

Suspension setting




AVAILABLE SETTINGS

Your motorcycle has adjustable suspensions, these adjustable settings are:

Front fork (KYB)

- Rebound (3) - located at the bottom of the fork.
- Compression (2) - located at the top of the fork.
- Air purge (1) - located at the top of the fork.
- Oil volume - 560 ml. (KYB 010M Oil)

Suspension setting



The volume of the oil in the fork, affects the level of the same inside and may be adjusted. A change in the volume, and therefore of the oil level will not affect the first part of the suspension travel, but it will affect the final part.

When the volume/oil level is increased, the suspension is more progressive and the action of the front fork is harder at the end of the travel.

When the volume/oil level is lowered, the suspension is less progressive and the action of the fork is less hard at the end of the travel.

If it is fork bottoming, it is recommended to slightly increase the oil level (approx 10 ml.).



WARNING

Make sure that both fork bottles have the same volume/oil level for regular performance.


Suspension setting

SUSPENSION SETTINGS

		KYB
Spring	From 65 to 75 kg.	4.0 N/mm
	From 75 to 85kg.	4.2 N/mm (STD)
	From 85 to 95kg.	4.4 N/mm
Rebound	Comfort	18 clicks from closed
	Standard	14 clicks from closed
	Sport	10 clicks from closed
Compression	Comfort	18 clicks from closed
	Standard	14 clicks from closed
	Sport	10 clicks from closed

		KYB
		200 / 300
Spring	From 65 to 75 kg.	50 N/mm
	From 75 to 85kg.	52 N/mm (STD)
	From 85 to 95kg.	54 N/mm
Rebound	Comfort	12 clicks from closed
	Standard	10 clicks from closed
	Sport	8 clicks from closed
Compression Low Speed	Comfort	14 clicks from closed
	Standard	12 clicks from closed
	Sport	10 clicks from closed
Compression High speed	Comfort	1-6/8
	Standard	1-3/8
	Sport	1


Suspension setting



Rear shock absorber (KYB).

- Rebound (1) - located at the bottom of the shock absorber.
- Low speed compression (2) - located at the top of the shock absorber (screw).
- High speed of compression 17mm. - located at the top of the shock absorber (4)
- Standard spring preload (3) - 252 mm, adjustable between 247 and 255 mm between its support planes.

-K spring 52N/m - ideal rider weight 75-85 kg.



Standard: 260 mm
Rango: 247-255 mm
Setting length: 252 mm

Suspension setting



STATIC SAG

To regulate the sag of the suspension follow the following steps:

1. Put the bike on an stand that allows you to keep the rear wheel in the air steadily.
2. Measure the vertical distance (1) between the rear axle nut and the upper fixed point.
3. Lower the bike from the stand and place it with both wheels on the floor (not resting on the side stand).
4. Measure the vertical distance between the rear axle nut and the upper fixed point.

If the difference between the measurements is different from 35 +/- 5 mm, vary the pre-load of the shock absorber until it is obtained.

The sag with the rider above the motorcycle should be 100 +/- 5 mm.

CORRECTION ACCORDING TO TYPE OF TERRAIN

Always leave the standard settings and only make changes if necessary.

Hard ground

Smooth the compression damping settings on both the fork and the shock absorber.

Sandy ground

Tighten the compression damping or replace the spring with a harder one on the fork. Hardening the compression and especially the rebound in the rear shock absorber can also help reduce the pre-load of the spring.

Muddy ground

Tighten the compression damping or replace the spring with a harder one on the fork. Hardening the compression and the rebound in the rear shock absorber, can also help increase the pre-load of the spring.

ADJUSTING YOUR MOTORCYCLE

Compression

- If you notice that the motorcycle wobbles or fluctuates widely even if the speed and obstacles are small, if it has a low driving position or has a tendency to bottom on downhill, you should harden the settings regarding the compression of both the fork and the shock absorber. If it cannot be corrected, it may be indicative of a too soft or fatigued spring, as well as low or insufficient SAE oil internally in the fork.
- If the motorcycle feels hard, especially over bumps, together with a lack of rear wheel traction and strong impacts from irregularities, you should soften the adjustment of the compression of both the fork and the shock absorber. If it cannot be corrected, it can be indicative of too hard a spring or an excessive oil level in the fork.

Suspension setting

Rebound

- **If the motorcycle feels unstable or soft**, if it easily loses its direction or oscillates widely, although the speed and obstacles are small, you must tighten the adjustment of the rebound in both the fork and the shock absorber. If it cannot be corrected, it may be indicative of a too soft or fatigued spring, as well as low or insufficient SAE oil internally in the fork.
- **If the motorcycle is rigid with short suspension travel**, along with lack of rear wheel traction and strong impacts of irregularities, you should soften the adjustment of the rebound in both the fork extension and the shock absorber. If it cannot be corrected, it can be indicative of too hard a spring or an excessive oil level in the fork.



WARNING

Make only one adjustment on the set each time and test the effect it has on the motorcycle.

Suspension adjustment is a very critical adjustment, because if it is not done correctly it can deprive even the best rider of full performance on the motorcycle. Check the suspension according to the rider and the terrain conditions.


When adjusting the suspension, you should not forget:

- If the bike is new, get used to the suspension for at least one hour of driving before making any changes.
- The factors to take into account are the weight of the rider, skill of the rider and the conditions of the terrain.
- If you have a problem, try changing your position on the bike to resolve it.
- The suspension must be adjusted to the rider's strengths. If you are fast on turns, you must adjust the suspension to this point.
- Make changes in small increments as it is very easy to get past.
- The front and rear suspension must be balanced.
- When evaluating suspension, the rider must strive to ride consciously and recognize the effects of the change. A poor driver's position and/or fatigue will lead to an incorrect judgement of the settings.
- When the change for a particular terrain is well adjusted, the references should be noted for when you encounter similar terrain the next time.
- Lubricate the swingarm bearings, tie-rods, rocker arms and joints before making changes to prevent excessive friction affecting suspension operation.

Centrifugal external adjustment system

ADJUSTMENT OF THE PRE-LOADING OF THE CENTRIFUGAL SPRING

Dismantling and adjustment:




1. Remove the plug (1) with a 27mm wrench.
2. Secure the adjustment screw (2) with a 2.5mm Allen key and loosen the locknut (3) with a 6mm angled spanner.
3. Tighten the screw (2) to the bottom and then tighten according to the recommendation table.

Assembly:

1. Secure the rotation of the adjustment screw (2) with a 2.5mm Allen key and tighten the locknut (3) with a 6mm angled spanner in order to lock the adjustment system.
2. Ensure the correct positioning and condition of the copper gasket (4) replace the plug (1) and tighten with a 27mm spanner and a maximum torque of 25Nm.

Adjustment	Pre-load value (mm)	Site conditions or circuit type	Engine performance.
1 turn	14.2 (300)	No grip (snow or mud)	Power and RPM limitation.
1.5 turn	14.6 (300)	Difficult grip or technical circuit	Smooth power delivery
2 turns (standard)	15 (300)	Correct grip or combination circuit	Optimum/standard
2.5 turns	15.4 (300)	Fast circuit	Live engine
3 turns	15.8 (200 / 300)	Very fast circuit	Low torque at low RPM and aggressive engine



TROUBLESHOOTING

Troubleshooting

Fault	Cause	Solution
Engine does not crank.	Seized crankshaft.	Contact the official GAS GAS official service.
	Seized cylinder/piston/connecting rod.	Contact the official GAS GAS official service.
	Seized transmission assembly.	Contact the official GAS GAS official service.
The electric starter does not crank ¹	The starter relay fuse is blown	Remove seat and check fuse.
	The battery is not charged	Remove the seat and check the charge.
The engine will not start.	Motorcycle has been inactive for a long time	Discharge the old fuel from the tank. When the tank is full of new fuel, the engine will start immediately.
	Dirty or wet spark plug.	Clean or dry the spark plug. If necessary, change it.
	The engine is flooded.	To unflood the engine, close the petrol, remove the spark plug, engage a gear and push the motorcycle several meters with the throttle fully open. Visually you will know when the pre-compression crankcase has been emptied. Mount the spark plug and start the bike. It is possible you may have to remove the spark plug again, if the pushing operation of the motorcycle has not been enough, the spark plug will get wet and must be cleaned. Repeat the push operation, fit the spark plug and the engine will start.  DANGER For your safety you must wrap the spark plug cap with a dry cloth. This will avoid a possible spark jump.
	Incorrect air/petrol mixture.	Clean the fuel tank breather. Adjust the air filter duct.
	Exhaust valve opened.	Check the exhaust valve and correct it.
The engine starts but stops again.	Incorrect air supply.	Close the choke. Clean the fuel tank breather hose. Adjust the air filter duct.
	Lack of fuel.	Fill the fuel tank.
The engine overheats.	Lack of coolant.	Add coolant. Check the cooling system for leaks.
	Radiator clogged or dirty.	Clean radiator fins or replace them.

Troubleshooting

It runs unevenly.	Spark plug dirty, broken or incorrectly adjusted.	Check the condition of the spark plug and clean it, adjust it or replace it.
	Spark plug cap problem.	Check the condition of the spark plug cap. Check the good contact of the cable with the cap and the cable itself. Change what is damaged.
	Ignition rotor damaged.	Change the rotor.
	Water in the fuel.	Empty the tank and put new fuel in
The engine lacks power or accelerates poorly.	The fuel supply is faulty.	Clean the fuel system and check it.
	Dirty air filter.	Clean or replace the air filter.
	Exhaust damaged or is leaking.	Check if the exhaust system is damaged, renew the fibreglass in the muffler if necessary.
	Dirty carburettor jets.	Remove the carburettor and clean the jets.
	Worn or damaged crankshaft bearings.	Contact the official GAS GAS official service.
The engine emits strange sounds.	Ignition problem.	Contact the official GAS GAS official service.
	Overheating.	See "The engine overheats".
The exhaust emits backfires.	Presence of carbon in the combustion chamber.	Contact the official GAS GAS official service.
	Poor quality petrol or bad octane.	Drain the petrol and introduce new and proper octane.
	Spark plug in poor condition or has inadequate specifications.	Replace spark plug with new and proper spark plug.
	Exhaust system gaskets are deteriorated.	Check if the exhaust system is damaged. The gaskets must be in perfect condition, otherwise change them for new ones.
The exhaust emits white smoke.	Damaged cylinder head gasket (leakage of coolant to the cylinder).	Contact the official GAS GAS official service.
The exhaust emits black smoke.	Clogged air filter.	Clean or replace the air filter.
	The main jet is too high.	Check main jet.
The gears are not engaged.	Clutch does not disengage.	Contact the official GAS GAS official service.
	Shift fork bent or blocked.	Contact the official GAS GAS official service.
	Gear locked in transmission.	Contact the official GAS GAS official service.
	Gear shift lever damaged.	Replace gear shift lever.
	Spring selector position loose or broken.	Contact the official GAS GAS official service.
	Broken shift drum.	Contact the official GAS GAS official service.
	Gear ratchet spring broken.	Contact the official GAS GAS official service.


Troubleshooting

The gears jump.	Worn shift fork.	Contact the official GAS GAS official service.
	Gear grooves worn.	Contact the official GAS GAS official service.
	Broken gear.	Contact the official GAS GAS official service.
	Damaged shift drum groove.	Contact the official GAS GAS official service.
	Worn shift fork axle	Contact the official GAS GAS official service.
	Selector position spring broken.	Contact the official GAS GAS official service.
The clutch slips.	Excessive clutch fluid level.	Check the level and adjust if necessary.
	Worn clutch discs.	Contact the official GAS GAS official service.
	Broken or weak clutch spring.	Contact the official GAS GAS official service.
The motorcycle is unstable.	Cable makes turning of the handlebar difficult.	Remove cable.
	The steering axle nut is too tight.	Adjust the steering axle nut.
	Damaged or worn steering bearings.	Contact the official GAS GAS official service.
	Bent steering axle.	Contact the official GAS GAS official service.
The damping is too hard.	Excessive fork oil level.	Remove excess oil to proper level.
	Front fork with too much oil viscosity.	Drain the oil from the fork and refill with an oil of suitable viscosity.
	Twisted front fork.	Contact the official GAS GAS official service.
	Too much pressure in the tire.	Check the tires pressure.
	Suspension poorly adjusted.	Adjust the suspension.
The damping is too soft.	Insufficient fork oil level.	Add oil to the proper level.
	Front fork with too little oil viscosity.	Drain the oil from the fork and refill with an oil of suitable viscosity.
	Low pressure in the tire	Check the tires pressure.
	Suspension poorly adjusted.	Adjust the suspension.
The motorcycle makes abnormal noises.	Chain badly adjusted.	Adjust chain tension.
	Worn chain.	Replace chain, front and rear sprocket.
	Worn rear sprocket teeth.	Change rear sprocket.
	Insufficient lubrication of the chain.	Lubricate chain with proper lubricant.
	Rear wheel misaligned.	Check the tension of the spokes of the rim. Readjust if necessary.
	Front fork spring weak or broken.	Replace front fork spring.
	Brake disc worn.	Replace the brake disc.
	Misplaced, worn or glazed pads	Reposition the pads or change them.
	Damaged cylinder.	Contact the official GAS GAS official service.
	Supports, nuts, bolts badly tightened.	Check and adjust to the appropriate tightening torques.

Troubleshooting

The handlebar vibrates.	Worn tire.	Replace the tire.
	Swingarm or its needle bearings are worn.	Contact the official GAS GAS official service.
	Offset rim.	Contact the official GAS GAS official service.
	Wheels out of alignment.	Check the tension of the spokes of the rim. Readjust if necessary.
	Steering axle with excessive tolerance.	Check steering head adjustment.
	Handlebar support loose, steering nut loose.	Check and adjust to the appropriate tightening torques.
The motorcycle tends to lean to one side.	Bent chassis.	Contact the official GAS GAS official service.
	Poorly adjusted steering.	Check steering play adjustment.
	Bent steering axle.	Contact the official GAS GAS official service.
	Bent front fork.	Contact the official GAS GAS official service.
	Wheels out of alignment.	Check the tension of the spokes of the rims.
The brakes do not work properly.	Worn brake discs.	Change the discs.
	Loss of brake fluid.	Contact the official GAS GAS official service.
	Impaired brake fluid.	Contact the official GAS GAS official service.
	Piston pump broken.	Contact the official GAS GAS official service.
	Worn brake pads.	Check and change pads if necessary.
The lamps are melted.	Defective voltage regulator.	Contact the official GAS GAS official service.
The lights' system does not work.	Connectors in bad condition, regulator with inadequate voltage output, check voltage stator	Clean/change connectors, check regulator, check voltage stator.

This page has been left blank intentionally.



WARRANTY MANUAL

Warranty manual

(According to Law 23/2003 of 10 July, on Guarantees for the Sale of Consumer Goods)

GAS GAS manufacturer's warranty rules.

The company **GAS GAS** (hereinafter GG) hereby guarantees to the end consumer, purchaser of a vehicle manufactured by GG, that both the materials and the manufacture are free from defects in accordance with the highest quality standards. Consequently, GG hereby warrants to the final purchaser (hereinafter the "purchaser"), in accordance with the conditions set forth below, the repair of any defects in materials or workmanship detected on a new motorcycle free of charge within the warranty period and without any limitation as to the number of kilometres travelled or the number of hours of operation.

Warranty period

The warranty period shall commence on the day of delivery of the vehicle to the purchaser by a GG licensing dealer, or in the case of demonstration models, on the date the vehicle first starts operating. The seller is liable for any lack of conformity which becomes manifest within the time period established under the Law 23/2003 of July on Warranties in the Sale of Consumer Goods from the time of delivery and in accordance with Directive 1999/44/EC for the rest of the Member States of the European Community. For countries outside the European Community, the warranty period will be governed by the rules in force. However, if the lack of conformity becomes apparent during the first six months from the date of delivery of the motorcycle, it is presumed that this fault existed when it was delivered; from the sixth month, the consumer must prove that the non-conformity existed at the time of delivery of the goods. During the first six months after the delivery of the repaired good, the seller shall be liable for any lack of conformity which motivated the repair.

Any defects detected in the product must be brought to the attention of a dealer authorized by GG within the warranty period. If the last day of the warranty period falls on a Sunday or an official holiday, the warranty period will be extended in such a way that the last day of the warranty period is the first business day after the Sunday or an official holiday.

Warranty claims for defects not brought to the attention of a dealer authorized by GG before the end of the warranty period will be excluded.

Obligations of the buyer

GG will be entitled to reject warranty claims if and to the extent that:

- a.) The buyer has not proceeded to subject the vehicle to any of the inspections and/or maintenance work required in the user manual or has exceeded the date stipulated for such inspections or maintenance work; also excluded from the warranty are any defects that appear before the date set for an inspection or maintenance work that would have never been carried out, or that will be carried out after the established date.
- b.) Inspection, maintenance work or repair carried out by third parties not recognized or authorized by GG.
- c.) Any maintenance or repair that has been carried out in breach of the technical requirements, specifications and instructions stated by the manufacturer.
- d.) Spare parts not authorized for use by GG in maintenance or repair work on the vehicle, or if, and to the extent that, the vehicle has been applied with fuels, lubricants or other liquids (including, but not limited to, cleaning products) that have not been expressly stipulated in the specifications of the User Manual.
- e.) The vehicle has in any way been altered or modified or equipped with components other than those expressly authorized by GG as admitted vehicle components.
- f.) The vehicle has been stored or transported in a manner inconsistent with the corresponding technical requirements.
- g.) The vehicle has been used for **a special use other than ordinary use**, such as competition, races or attempts to obtain a record.
- h.) The vehicle has suffered a fall or accident that directly or indirectly causes damage.

Warranty exclusions

The following items will be excluded from the warranty:

- a.) Worn parts, including, but not limited to, spark plugs, batteries, fuel filters, oil filter element, chains (secondary), engine output sprockets, rear sprockets, air filters, brake discs, brake pads, clutch discs, bulbs, fuses, carbon brushes, footrests, tires, chambers, cables and other rubber components.
- b.) Lubricants (e.g. oil, grease, etc.) and operating fluids (e.g. battery fluid, coolant, etc.).

Warranty manual

- c.) Inspection, adjustment and other maintenance work, as well as all types of cleaning work.
- d.) Paint damage and consequent corrosion due to external influences such as stones, salt, industrial exhaust fumes and other environmental impacts or improper cleaning with improper products.
- e.) Damage caused by defects, as well as expenses caused directly or indirectly by incidents of defects (for example, communication expenses, accommodation expenses, car rental expenses, public transportation expenses, crane expenses, express courier charges, etc.), as well as other financial damages (for example, caused by loss of use of a vehicle, loss of revenue, loss of time, etc.).
- f.) Acoustic or aesthetic phenomenon that does not significantly affect the condition of use of the motorcycle (e.g. small or hidden imperfections, normal noise or vibration of use, etc.).
- g.) Phenomena due to the ageing of the vehicle (for example, discolouration of painted or metal coated surfaces).

Various

- 1.) In the event that the repair or replacement of the part will be disproportionate, GG will have the prerogative to decide at its sole discretion whether to repair or replace defective parts. The owner of the spare parts, if any, will be GG, without any other consideration. The GG authorized dealer who has been entrusted with the repair of defects will not be authorized to make binding declarations on behalf of GG.
- 2.) In cases of doubt as to the existence of a defect or if a visual or material inspection is required, GG reserves the right to require the shipment of the parts on which a warranty claim is based or to request a review of the defect by a GG expert. Any additional warranty obligations on parts replaced free of charge or any service provided free of charge under this warranty will be excluded. The warranty for spare parts within the warranty period will expire on the expiration date of the warranty period of the respective product.
- 3.) If a defect cannot be repaired and its replacement is disproportionate to the manufacturer, the secured consumer shall be entitled to cancellation of the contract (payment of compensation) or partial reimbursement of the purchase price (discount), instead of motorcycle repair.
- 4.) The warranty claims of the buyer under the contract of sale with the corresponding authorized dealer will not be affected by this warranty. This warranty does not affect the buyer's additional contractual rights under the general conditions of business of the authorized dealer. Such additional rights, however, can only be claimed from the authorized dealer.
- 5.) If the buyer resells the product within the warranty period, the terms and conditions of this warranty will continue to exist to the current extent, so that the claim rights under this warranty in accordance with the terms and conditions set forth in this document will be transferred to the new owner of the motorcycle.



ENDURO SERIES