

MAP SWITCH MANUAL MR300i 2025

Press MAP button less than 1 second, the blue LED flashes to indicate currently selected map

1 flash : Map 1 selected

2 flashes : Map 2 selected

3 flashes : Map 2 selected



Press MAP button 3 seconds to switch to the next map. The blue LED will flash to confirm the new selection.

1 flash : Map 1 selected

2 flashes : Map 2 selected

3 flashes : Map 2 selected



The blue LED has two intensity levels

- Low intensity : Default mode, button is not being used.
- High Intensity flashes : Occur when changing the map or when checking the current map, to indicate confirmation

